



## Wrap 45 Installation Instructions

The package includes the following items;

1. One (1) wrap containing 14 boards of 1" x 4 5/8" x 34 1/8" Re-plast lumber attached to 3/4" x 1 1/2" Polyboard.
2. One (1) pre-drilled board, 1" x 4 5/8" x 34 1/8" Re-plast lumber with six pre-drilled plugs in the back of the Re-plast lumber.
3. One (1) pre-drilled board, 1" x 4 5/8" x 34 1/8" Re-plast lumber with two 7/8" x 1 1/2" notches and six pre-drilled plugs in the back of the Re-plast lumber.
4. One (1) aluminum-mounting bracket.
5. Eight (8) 8 x 1 1/2" Yellow Zinc Tech Screws.
6. Two (2) 3/8 x 1 1/2" Stainless Hexagon Socket Button Head Cap Bolt.
7. Two (2) 3/8 Stainless Flanger Nut.

### Required Tools

- 5/16" nut driver or flat screwdriver
- ratchet tie down with minimum 8 ft of strap

### Installation Instructions (Two people recommended)

**Ensure the Wrap is installed at room temperature. (17-20C) (70-75F). The material is easier to work with and there will room for expansion and contraction in colder and warmer climates.**

1. Place adequate protection (moving blanket is best) underneath entire length of wrap to prevent any scratches to outside surface.
2. Lay the strap of the tie down running lengthwise in the center of the blanket.
3. Lay wrap on a flat smooth surface finish side down, with the routed finished edge being the top opening of the drum.
4. Lay drum on wrap between the 1 1/2" wide bands making sure that the bottom of the unfinished wrap extends an 1 1/4" – 2" past bottom of can and top of the finished wrap is a minimum of 1" below the top of the lip of the drum. The space between the top of the wrap and the top of the drum is important. (Minimum of 1" clearance is needed for garbage bag to fit properly).
5. Having in hand either the flat screwdriver or 5/16" nut driver, reach over and roll wrap together lining up the gear clamps. Use the ratchet tie down to bring the two ends together. Gradually screw the wrap tighter together. **DO NOT OVERTIGHTEN.** Ensure there is equal spacing on top and bottom. Take the 2 unfastened boards (included) and tighten or loosen the clamps ensuring there is room to fit. **DO NOT FASTEN THESE BOARDS AT THIS TIME.**
6. Fasten aluminum angle bracket where the re-plast wood is notched out near bottom of wrap with bolt and nut provided.
7. Stand drum and Wrap upright.

### Optional Lid Installation:

**HOLD THE 2 UN-FASTEN BOARDS IN POSITION**

If using the plastic 27" Dome Top Lid, ensure it fits flush over top of the Drum and Wrap. If using the Steel Funnel Lid or the 24" Dome Top Lid, ensure they sit either between the wrap and the drum or over the drum and allow small space between it and top of the wrap. It will be necessary to adjust the gear clamps in or out to accommodate the lids. **TRY AND AVOID MAKING THE WRAP TOO TIGHT AROUND THE DRUM.**

8. Carefully tap out the 4 plugs with a small flat screwdriver that are predrilled on the back of each of the 2 boards. Install remaining 2 boards using 1 1/2" tech screws provided, saving the notched board for last. Be careful not to drive screw to deep through boards.
9. Tap in plugs to hide screw holes until flush with surface using a hammer and wood block
10. If using one of the lid options, attach the cable in the pre-drilled hole on top of the wrap with the nut and bolt provided.