



Wishbone
site furnishings

Installation Procedure
Securing Wishbone Picnic Tables to Concrete Pads
Concrete Anchor Option
(November 2011)



Required Tools and Materials

- ✓ Concrete hammer drill
- ✓ 1/2" concrete drill bit
- ✓ Hammer
- ✓ Air compressor or hollow tube
- ✓ Measuring tape
- ✓ 7/32" Allen (hex) key
- ✓ Felt marker
- ✓ Silicone
- ✓ Paint pen

Wishbone recommends purchasing a stainless steel bolt down kit #INST-1

1. Position table on concrete pad. Mark holes for concrete anchors with felt marker/paint pen.



2. Remove the table.

3. Set the depth of the drill bit to the length of the anchor using tape.



4. Drill the holes to the depth required – ensure drill is straight, perpendicular to ground.



5. Blow out the holes to remove all the concrete dust and debris – compressed air or blow through hollow tube.



6. Insert concrete anchor - hammer the anchor with the supplied post to expand the base securing it to the concrete.



7. Position table on concrete pad such that the holes line up.



8. Secure table to the anchor with bolt supplied.



9. Paint the top of the fastener with a color paint pen to match the table.



10. Ready for use !!



Picnic Table Installation on Concrete Pad – Concrete Anchor